

## Carpet and All Weather Floor Mat Inspection and Installation Instructions



1. Make sure the floor mat is properly secured by the retaining hooks (clips). Confirm that the retaining hooks (clips) are secured into the grommet holes in the vehicle's floor (carpet). Warning: Do not stack the floor mats in any vehicle. The retaining hooks (clips) are designed to accommodate only one floor mat at a time.



- 2. Check the following pedal operation (fully depress the pedal) to assure the AWFM does not interfere with it. Make sure the vehicle is turned off and in the "Park" position when testing:
- Accelerator Pedal
- Brake Pedal
- · Clutch Pedal (if equipped)

## Floor Mat Installation

If you are installing Carpeted or All Weather Floor Mats for the first time, please follow these important instructions.

- 1. Carefully read the General Floor Mat Warnings.
- 2. Check for correct part number on the packaging label as well as on the floor mats to confirm vehicle applicability.
- 3. Check for correct model name on the packaging label to confirm vehicle application.
- 4. Carefully read the warning tag attached to the driver's floor mat regarding installation.
- 5. Install only the driver's floor mat in the driver's foot area.
- 6. Do not install more than one floor mat in the driver's foot area.
- 7. Follow the floor mat retention clip installation instructions supplied with the clips. The retaining hooks (clips) are supplied in the bag with the floor mats (in the case of Lexus, the hooks (clips) are supplied with the carpet floor mats.
- 8. Ensure all retaining hooks (clips) supplied with the floor mats are securely installed to the vehicle floor carpet's grommet holes.
- 9. Install the floor mats securely to the retaining hooks (clips).
- 10. Verify the driver's floor mat is secured to the vehicle floor by the retaining hooks (clips).
- 11. Check the following pedal operation to assure the floor mat does not interfere with it:
- ° Accelerator Pedal
- ° Brake Pedal
- ° Clutch Pedal (if equipped



## Read these important Warnings BEFORE installing ANY type of Floor Mat. General Floor Mat Warnings

- Only install floor mats designed specifically for that model and model year. This applies both to All Weather Floor Mats as well as carpet floor mats.
- ° Never install a floor mat if you are uncertain of the model application.
- ° Never install the passenger floor mat in the driver's position.
- ° Never install the floor mat upside down.
- Always properly secure the driver's floor mat using the retaining hooks (clips) supplied in the bag with the floor mats (in the case of Lexus with the carpet floor mats). If the mat is properly secured and you have confirmed vehicle applicability, it will not interfere with the accelerator pedal.
- ° Never install the front driver's floor mat without all retaining hooks (clips) securing the mat firmly in place.
- The retaining hooks (clips) are designed to accommodate only one floor mat at a time.
- ° Do not install another floor mat(s) on top of an existing driver's floor mat.
- Never turn the driver's floor mat over to keep the mat's top side clean or from wearing out.
- After installation, always check the operation of the accelerator, brake and clutch (if applicable) pedals to assure the floor mat does not interfere with them.